

SAFECRAFT Model LT Spare Charged Fire Extinguisher

The following instructions will help you install your existing discharge head on the SAFECRAFT LT/LS charged cylinder.

- 1) Remove the actuating head from the empty bottle by :
 - a) Using a small punch, tap out the roll pin on the top of the discharge head. Drive it out from the front of the head. Keep the pin.
 - b) Loosen the set screw on the side on the discharge head.
 - c) Pull the top of the discharge head off.

- 2) Re-Set the plunger by:
 - a) Remove the looped safety pin is installed.
 - b) Insert the plunger with the spring into the bottom of the discharge head.
 - c) Place plunger vertical on a hard surface and depress the discharge head top with the palm of the hand until the plunger bottoms in the head.
 - d) Insert the safety pin.

CAUTION: The plunger is now capable to discharge the extinguisher again. DO NOT remove the safety pin until the actuation cable is installed.

Note: You may have to lubricate the “O” ring on the head – any general purpose grease will do.

- 3) Insert the discharge head top onto the bottle head, it may snap into the head.
- 4) Tap in the roll from the front of the head – otherwise the head may loosen on the cylinder and cause a leak..
- 5) Attach the lanyard to the safety pin.
- 6) Install the extinguisher in the vehicle.
- 7) Install the actuation cable.

Remove the pull pin only when racing – the pin must be removed for the extinguisher to operate